



How to Measure Your Existing Windows

Thanks for choosing Magnetite as the sound control and thermal efficiency solution for your windows. These instructions will cover how to properly measure your windows in preparation for ordering your Magnetite acrylic window panels. Measuring can be done with a variety of tools; however, these instructions will cover the use of a standard tape measure.





Step 1:

Make sure that you have the space to move in front of your window.

Be sure to move all obstacles and window treatments that may get in the way.

Note: For all measurements, make sure that the tape measure is pushed securely into the window box and then take the measurement to the nearest $\frac{1}{8}$ inch mark.

Measurement Notes:



Step 2:

With the window area clear, measure the width of the base of the window box.

Measurement Notes:



Step 3:

Measure the width of the top of the window box.

Measurement Notes:



Step 4:

Measure the height of the left side of the window box.

Measurement Notes:



Step 5:

Measure the height of the right side of the window box.

Measurement Notes:



Step 6:

Measure the right diagonal dimension of the window box.

Measurement Notes:



Step 7:

Measure the left diagonal dimension of the window box.

Note: For Steps 6 & 7, make sure that you measure from the very corner on the top to the very corner on the bottom.

Taking these measurements may be easier with the assistance of a second person.

Measurement Notes:



Step 8:

Repeat Steps 1 through 7 for each window that would like Magnetite installed.


Measurement Notes:



Step 9:

Submit all six (6) of these window measurements for each of your windows to Magnetite Southwest for the construction of your custom Magnetite acrylic window panels.

Measurement Notes:



Optional Step 10:

If you would like to have your Magnetite acrylic come as more than one panel for a hung or slider window, measure from the top of the window box to the center of your window sash.

Note: If your window is a horizontal slider, take this measurement from the left side of the window box to the center of the window sash.

Measurement Notes:



IT'S NOT A WINDOW...IT'S

Magnetite

www.magnetite.com



Measurement Sheet

Use this sheet to help keep all of your measurements in order.

Window #1

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #2

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #3

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #4

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #5

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #6

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #7

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #8

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #9

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____



Measurement Sheet Continued

Use this sheet to help keep all of your measurements in order.

Window #10

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #11

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #12

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #13

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #14

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #15

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #16

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #17

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____

Window #18

- 1. _____ 5. _____
- 2. _____ 6. _____
- 3. _____ *7. _____
- 4. _____



IT'S NOT A WINDOW...IT'S

Magnetite

www.magnetite.com